

INSTALLATION TIPS

MOLDING & VALANCE INSTALLATION

It is important to know how to properly install moldings. Euro-Rite offers 4 different types of crown:

CM = standard

CMS = shaker crown

CMC = colonial crown

CMB = bull-nose crown and 2 different valance options

This chart shows what crown options you have with our door styles. See page 4.3 for crown prices.

DOOR STYLE	TYPE OF CROWN
San Juan (R)	CM, CMC
Saltspring (FO)	CM, CMC
Bowen (RO)	CM, CMC
Cortes (M)	CM, CMS, CMC
Rainier (RM)	CM, CMS, CMC
Cascade (RA)	CM, CMS, CMC
Monterrey (AB, OW, BW, CP, FM)	CMB, CM*, CMS* (*chocolate pear only)
Santos (VW, VAW)	CM, CMS, CMC
Solaire (FPW, FPCP, FPWC)	CM, CMS, CMC
Seymour (FAW)	CM, CMS, CMC
Capilano (RAW)	CM, CMS, CMC
Cyprus (SCPS, SWCS, SSS, SHNS)	CM, CMS, CMC
Langdale (RCPS, RWCS, RSS, RHNS)	CM, CMS, CMC

When installing molding there are a few options. This diagram shows all the applicable applications.

Tips to Remember:

1. Ceilings are not always square.
2. With an 8" ceiling and 42"H upper wall cabinets, crown should not be used. 36"H are ok to use.

See the following chart for molding installation diagrams.

INSTALLATION TIPS

OPTIONS FOR INSTALLING CROWN & VALANCE DIAGRAMS

