


# Assembly Instructions









Laundry 3 Door Wall Cabinet



W5424-H






<b>8</b> 0540 0005	<b>8</b> 0540 0025	<b>16</b> 0540 0015	<b>4</b> 0540 0045
<b>4</b> 0540 0030	<b>4</b> 0550 0005	<b>6</b> 0540 0065	<b>3</b> 0550 0025
<b>6</b> 0510 0055	<b>6</b> 0510 0100	<b>3</b> 0550 0080	



## 1




## 2




## 3

- C1 → A1
- C2 → A1
- D1 → A1
- D2 → A1




4

G → C1 & C2  
G → A1  
A2 → G, C1 & C2




5

x 4  
B → C1 & C2




6

x 4




7


x 4








8



X 3




9




10

X 3



11



X 3

